## **Copy Disc to Disc**

- 1. Power on the Reflex and Set your Source to the top drive.
- 2. Load the drives with the desired number of blank discs.
- 3. The screen will display 1.Copy press ...
- 4. Screen may display Load and copy? If it does Press
- 5. Screen may display No Counter? If it does Press
- 6. The Reflex will then begin preparing and then copying to the blank discs.
- Once the process is complete the drives will eject the successful copies and the screen will give a count of passed and failed discs.
- 8. When the copy process is finished and you would like to use a new master press the