

3. The LCD Control Panel

Figure 1-4 below shows the LCD Control Panel. This panel has a two-line by 20 character LCD display to provide user feedback and eight push buttons to control the of the Disc Makers ReflexAuto operation. The functions for these buttons are shown in Table 1-1.



Figure 1-4 LCD Control Panel Layout

Table 1-1: Front Panel Controls

Control	Name	Function
	Up	Scroll up through the menu or list.
	Down	Scroll down through the menu or list.
	Enter	Execute the function. Also called OK in the Menus.
	ESC	Go back to the previous function.
Master	Master	Quick Key to put machine in the correct Master Mode.
Load	Load	Quick key to load a master disc to the units internal hard drive
Info	Info	Quick key to see system, master disc, and hard drive image information including partition size, disc size, disc type, drive and system firmware versions.
Shutdown	Shutdown	Quick key to properly turn off the unit.